




Leaf Lamp Series

G
Green Furniture Concept

Leaf Lamp Tree M Connecting Cables


Important! Always shut off power to the circuit before starting installation work. In some countries electrical installation work may only be carried out by a authorised electrical contractor. Contact your local electricity authority for advice.




6 x Slimline Male Wieland




1 x Wieland Adaptor Block



1 x Small Wieland Adaptor Block



1 x Wieland Connector Female to Male



1 x Schucko Contact



Maintenance Leaf Lamp & Leaf Lamp Tree


Tools: Use an electric leaf blower. If this is not available it's advisable to use compressed air.

Course of action: Clean the lamp at evening or night time and wipe off the floor in the morning. Blow through the whole lamp, this takes about 5 minutes with leaf blower and 30 min with compressed air. Blow so that the leaves flutter, just as they do in nature. If you have multiple lamps in a cluster, repeat the process for each lamp.


Recommended intervals: Clean every 6th to 24th month. Clean up more often where more people move, for example shopping malls or airports, and less often where fewer people move, for example offices. Dust can be seen more easily on colored leaves, so they require a more frequent interval.

Around-the-clock businesses or small scale facilities: Dust off with a dustbin and cross through the foliage.

Warning: Do not use a vacuum cleaner because it will eat the leaves.




1. Leaf Blower




2. Compressed air




3. Duster



No vacuum cleaner



Don't wait too long between cleaning sessions



G

Green Furniture Concept